


















## Enabling the new £20 polymer note



### IMPORTANT

Before following these instructions, it is necessary to close the count, to do this, with the unit showing the denomination screen press the  key then press the  key and the unit will show a message '**Count in Progress**' now press the  key.

1. Use the  key to select '**Setup Wizard**' and then press the  key.
2. Use the  key to select '**Note Wizard**' and press the  key.
3. When you are asked for a PIN number press the arrow keys in the following order , , , .
4. Use the  key to select '**£20N**' and press the right-hand soft key  labelled '**Change**' to change the **X** to a ✓.
5. Press  key to save.
6. New £20N notes are now set on your unit. Press the  key to return to normal counting.

If you require assistance then please call the customer helpline on:

**01633 27 68 68**